



Stalų sistema UNIKA
Desk system UNIKA




UNIKA A

2.....6




UNIKA U

2.....6



UNIKA ERGO


7.....14




UNIKA LINAK

15.....24


UNIKA A




UNIKA U



* Dėmesio! Stalviršio gręžimas yra universalus ir tinka visiems Unika serijos stalams.
* Attention! The tabletop drill is universal and suitable for all Unika series tables.






B02EA5901



M8x16

X16

B03HA1501



D8

X16


B022A1801




4x20

X9



B011C01XX



X4



Varžtus susukti, bet nepriveržti /
twist the screw but not too tight





Svarbu:

1. Priveržti visus varžtus iš sono
2. Priveržti visus varžtus iš viršaus


Important to:

1. Tighten all the screws from the side
2. Tighten all the screws from above







UNIKA ERGO




* Dėmesio! Stalviršio gręžimas yra universalus ir tinka visiems Unika serijos stalams.
 * Attention! The tabletop drill is universal and suitable for all Unika series tables.






M8x20



X4

M8x20



X10

M8



X2

L- 1200 mm

L-1400 mm

L-1600 mm

L-1800 mm

3.5x16



X2

4.5x16




X18

4.5x25




X2




X4



X1



X1



X1

L- 1800 mm

M8x16



X6

M8



X6

4x20




X8

L- 1200 mm


L-1400 mm

L-1600 mm


L-1800 mm




X2




X4



X2




X2




X2


L- 1800 mm




M8x20




L- 1200 mm
X2




L- 1400 mm
X2





L- 1600 mm
X2





L- 1800 mm
X2














M8x16



Užveržimo momentas
neturi viršyti maks. 10 Nm
The thrust moment must
not exceed max. 10 Nm










*Išreguliuotą stalą įjungiame
į elektros tinklą*

*Turn the table around to standing
position and plug the cable in*





DĖMESIO!

Prieš pirmą stalo naudojimą ir kiekvieną kartą, kai stalas bus iš naujo įjungtas į elektros tinklą, reikės atlikti šiuos veiksmus:

- 1. Spauskite mygtuką "žemyn", kol stalas bus visiškai nuleistas. Laikykite nuspaustą mygtuką tol, kol stalas nejudės.*
- 2. Dabar stalą galima pakelti aukštyn.*


ATTENTION!

Before using the table for the first time and each time the table is reconnected to the power socket, the following steps will be required:

- 1. Press the "down" key until the desk is lowered completely. Hold the key until the desk no longer moves.*
- 2. Reactivate the down key and hold until the desk no longer moves. Now the desk can be raised.*




UNIKA LINAK




* Dėmesio! Stalviršio gręžimas yra universalus ir tinka visiems Unika serijos stalams.

* Attention! The tabletop drill is universal and suitable for all Unika series tables.



M6x40



X8

M6x12



X4

M6



X4

M6x16




X8

5x16



X8

5x45



X2

5x55




X6

3x16




X3


4x35




X2



X4




X3




X2




X2




X2



X2




X2




X1




X2






X1





X1







Užveržimo momentas
neturi viršyti maks. 7 Nm
The thrust moment must
not exceed max. 7 Nm





Užveržimo momentas
neturi viršyti maks. 7 Nm
The thrust moment must
not exceed max. 7 Nm



















M6x40



Užveržimo momentas
neturi viršyti maks. 7 Nm
The thrust moment must
not exceed max. 7 Nm

X2




X4








220V~





*Dirželiais kabančius
laidus tvirtiname
prie stalviršio apačios*

*If it's necessary
you can fasten
the wires to
the table top*




*Išreguliuotą stalą įjungiame
į elektros tinklą*

*Turn the table around to standing
position and plug the cable in*



X4

*Paruoštas naudoti!
Ready to use!*



DĖMESIO!

Prieš pirmą stalo naudojimą ir kiekvieną kartą, kai stalas bus iš naujo įjungtas į elektros tinklą, reikės atlikti šiuos veiksmus:

- 1. Spauskite mygtuką "žemyn", kol stalas bus visiškai nuleistas. Laikykite nuspaustą mygtuką tol, kol stalas nejudės.*
- 2. Dabar stalą galima pakelti aukštyn.*



ATTENTION!

Before using the table for the first time and each time the table is reconnected to the power socket, the following steps will be required:

- 1. Press the "down" key until the desk is lowered completely. Hold the key until the desk no longer moves.*
- 2. Reactivate the down key and hold until the desk no longer moves. Now the desk can be raised.*